



ELECTRONICAL VOICE ASSISTANT **E.V.A.**

Lie down, close your eyes and enjoy! The Electronic Voice Assistant (E.V.A.) means that, for the first time, the sunbed can be operated using voice commands. The Electronic Voice Assistant (E.V.A.) can be activated with just one click on the large external display.

1) STARTING VOICE INPUT

Touch the display or say "EVA" at low music volume.

2) GIVING VOICE COMMANDS

ADJUSTABLE FUNCTIONS:

Foot ventilation, Body ventilation, Facial ventilation, Temperature, Facial lamps, Body lamps, LEDs, Aqua Fresh face, Aqua Fresh body, Aqua Fresh complete, Aroma, Voice Guide, Volume, Music source, Track.

SIX SETTINGS:

Plus / Minus, Maximum / Minimum, On / Off

Examples of voice commands:


- Facial ventilation plus ➔ The facial ventilation is increased by one setting.
- Facial lamps minus ➔ The UV intensity for the face is reduced by one setting.
- Body ventilation maximum ➔ The body ventilation is set on the maximum level.
- Temperature minimum ➔ The temperature is set to the lowest temperature
- Aroma on ➔ The aroma scent is turned on.
- Aqua Fresh off ➔ Aqua Fresh is turned off.

Ergoline

BEFORE USE:

ACTIVATE VOICE CONTROL VIA THE MICROPHONE BUTTON.
 Tap the microphone button to activate the voice control E.V.A.
 A short explanatory video starts in the outdoor display, which can be ended at any time by touching the display.

If the microphone symbol is highlighted in colour, the voice control E.V.A. is activated. Touch the display during tanning, to give voice commands or to operate as usual.



VOICE COMMANDES DURING TANNING:

TOUCH THE DISPLAY or say "EVA" at low music volume.

An „acoustic signal“ follows as confirmation and the brightness of the LEDs is dimmed. Music volume and ventilation will be temporarily reduced so that E.V.A. can better understand you. If voice control is not used for several seconds, the music volume and ventilation are increased again. Touch the display or say „EVA“ again to give further voice commands.

NAME THE FUNCTION YOU WANT TO ADJUST AND THE REQUIRED SETTING:

- PLUS / MINUS: The function will be increased or reduced by one setting
- MAXIMUM / MINIMUM: The function will be set to the maximum or minimum setting.
- ON / OFF: The function will be switched on or off.

Each recognised voice command will be confirmed by an “acoustic signal”.
 Voice commands are not possible when the voice guide tracks are being played.

SELECTION OF POSSIBLE SETTINGS:

	UV Facial lamps Plus	UV Facial lamps Minus	UV Facial lamps Maximum	UV Facial lamps Minimum
	UV Body lamps Plus	UV Body lamps Minus	UV Body lamps Maximum	UV Body lamps Minimum
	LEDs Plus	LEDs Minus	LEDs Maximum	LEDs Minimum
	Facial ventilation Plus	Facial ventilation Minus	Facial ventilation Maximum	Facial ventilation Minimum
	Body ventilation Plus	Body ventilation Minus	Body ventilation Maximum	Body ventilation Minimum
	Foot ventilation Plus	Foot ventilation Minus	Foot ventilation Maximum	Foot ventilation Minimum
	Temperature Plus	Temperature Minus	Temperature Maximum	Temperature Minimum
	Aqua Fresh Face on	Aqua Fresh Body on	Aqua Fresh On completely	Aqua Fresh Off
	Own music On	Internal music On	Studio music On	Music Off

	Voice Guide On	Voice Guide Off
	Volume Plus	Volume Minus
	Track Plus	Track Minus
	Aroma On	Aroma Off

Ergoline